

## Installation Instructions for Termistop Bathtraps



- Remove blockout (box, tray, etc.) Make sure surface of pipe is clean. Place Termistop Bathtrap on top of pipe as shown . Tighten clamp at top of pipe.



- Cut an "X" at the top of the pipe clamp as shown. Making sure to cut with the grain of the mesh.



- Fold tabs over edge of clamp. Loosen clamp and lower Bathtrap to surface of the vapor barrier. Tighten clamp.



- Flatten Bathtrap out onto vapor barrier as shown. Make sure the edges of the Bathtrap are folded up as shown in the photo to the right. Replace blockout (box, tray, foam, etc.). Place Termitape on top of pipe.